

Adapter for converting from a 40-pin DIL package to a 120-pin QFP package for MCUs of MB96300 series from Fujitsu (e.g. MB96F386RSA, MB96F387YSA).



Please follow the pictures below to connect the adapter onto the GALEP in the right orientation, and to correctly place the programmable device into the adapter.

Caution! Before using the adapter all the 4 jumpers must be placed at position **OFF** or at position **ON**.


Adapter für die Umsetzung 40-polig DIL auf 120-polig QFP für MCUs der MB96300-Serie von Fujitsu (z.B. MB96F386RSA, MB96F387YSA).

Bitte beachten Sie die folgenden Bilder für den richtigen Einsatz im GALEP und das richtige Einlegen des Bauteils in den Adapter.

Achtung! Vor der Benutzung des Adapters müssen alle 4 Steckbrücken auf Position **OFF** oder Position **ON** gesteckt werden .



Position **OFF**



Position **ON**

